
















Exploded diagram and spare parts list (T315) Rev.3

Machine	Explode	Code	Description
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	1	AA562	Plastic Window on Door
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	2		Front Door
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	3		Front Inner Tank
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	4		Back Door
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	5		Back Inner Tank
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	6	AA609	Left Panel
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	7		Evaporator Blocker
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	8	AB216	Inner Tank
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	9		Synchronous Motor
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	10	AA233	Control Board Box
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	11	AA559	Control Board(R134a)
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	11	AG873	Control Board(R600a)
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	12	AA563	Suction Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	13	AA592	Reservior
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	14		Fan Motor
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	15	AA584	Fan Tool
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	16		Condenser
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	17	AA565	"T" Type Connector
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	18	AA566	Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	19	AA567	Electromagnetic Valve
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	20		Compressor(R134a)
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	20	AG874	Compressor(R600a)
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	21	AA611	Back Panel
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	22	AA585	Filter
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	23	AA568	Wiring Board
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	24	AA569	Drainage Connector Screw
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	25		Drainage Connector
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	26	AA595	"T" Type Stemming
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	27	AA596	Drainage Connector
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	28	AA597	Inlet Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	29	AA598	Inlet Pipe Fixer
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	30	AA571	Feet
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	31	AA599	Back Fortified Fixer
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	32	AA178	Wire Fixer
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	33	AA612	Bottom Board
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	34	AA560	Pump
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	35	AA601	Silica Gel Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	36	AA602	Silica Gel Connector
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	37	AB203	Strainer
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	38	AA573	Drainage Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	39	AA574	Seal Washer
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	40	AA575	Nut Of Drainage Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	41		Bottom Board
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	42	AA576	Positional Switch Board--AA614
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	43		Positional Switch

Exploded diagram and spare parts list (T315) Rev.3

T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	44	AA603	Water Box Rotational Axis
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	45		Heat Preservation Foam
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	46	AA561	Ice Cube Chamber Full Sensor
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	47	AA615	Right Side Panel
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	48		Front Panel
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	49		Evaporator
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	50	AA618	Ice Cube Chamber
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	51	AA557	Ice Pusher
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	52	AA586	Water Filter Board
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	53	AA577	Operation Panel
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	54	AA578	Operation Panel Fixer
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	55	AA579	Operation Panel Sticker
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	56	AA604	Ice Storage Basket
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	57	AA605	Ice Scoop
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	58		Slicon pipe L=180mm
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	59	AB089	Water Temperature Sensor
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	60		Drainage Elbow Connection Pipe
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	61		Axle Sleeve
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	62	AA233	Control Box Cover
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	63		Condenser Sensor
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	64		Power Cord
T315 Polar Manual Fill Ice Cube Maker - 11kg/24hr	65		Power Cord Tap