






























Machine	Explode	Code	Description
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	1		Support
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	2	AK099	Shelf
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	3		Spring
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	4		Wheel Support
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	5	AG257	Back Wheel
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	6	AK096	Handle
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	7		Door
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	8		Thermostat Box Cover
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	9	AB363	Thermostat
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	10		Thermostat Support
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	11		Thermostat Box
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	12	AA639	Sensor Fixed Clip
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	14	AC614	Sensor
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	15		Body
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	16		Unite Board
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	17	AD202	Condenser
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	18		Condenser Cover Board
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	19	AJ520	Condenser Fan & Blade
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	20		Basket Guard Grills
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	21	AG014	Compressor(R600a)
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	22	AK100	Water Box
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	23		Plug
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	24		Air Flow Grille
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	25		Right Ornament L=340
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	25		Right Ornament L=335
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	26		Ornament Clip
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	27		Back Ornament L=1258
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	27		Back Ornament L=1254.5
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	28		Bottle Cap Box
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	29		Bottle Opener
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	30		Air Conduct Board Left Support
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	31		Air Conduct Board Right Support
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	32		Air Conduct Board
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	33	AJ506	Lock & Key
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	34		Lock Box
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	35		Left Ornament L=340
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	35		Left Ornament L=335
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	36	AK101	Evaporator
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	37	AG253	Evaporator Fixer
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	38	AB339	Circle Fan
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	39		Basket Guard Grills
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	40		Fan Support
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	41		Shelf Protector Pin
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	42	AB120	Filter Drier
CT331 - Polar bovenlader flessen/fustenkoeler 417 liter	N/A	AJ162	Electrics for Compressor HPKD190A